TOUCH LIFE.

MOTOROLA **QUENCH**™ with MOTOBLUR™

Welcome

MOTOROLA **QUENCH** with MOTOBLUR™ syncs contacts, posts, feeds, messages, e-mails, photos and much more—from sources like Facebook™, Twitter, MySpace, Gmail™, your work e-mail, Picasa™, Photobucket, LastFM—and serves it up just the way you want it.

Your phone

Most of what you need is in the touchscreen and three simple keys on the front:

- **Home:** Go to the home screen. Then, touch for apps.
- **Menu:** Open menu options.
- **Back:** Go back a screen.

If you want a full keyboard (good for texting, browsing, or searching in your **Contacts** list), just turn the phone—the screen spins to stay right-side up.

Let's go

Let's get you up and running.

Tip: Your phone comes with a microSD memory card already installed. It's right next to your SIM card.

Caution: Before assembling, charging or using your phone for the first time, please read the important **Safety, Regulatory & Legal** information provided with your phone.

Create or log into a MOTOBLUR account. Enter your name, your email address (for account information), and a new MOTOBLUR password. Registration is secure, and should only take a few minutes.

Note: To use MOTOBLUR, please read the terms and conditions during registration and, if you agree, check **Agree**.

Touch

It's all in the touch:

- **Touch:** Choose an icon or option.
- **Touch & Hold:** Open options.
- **Drag:** Scroll or move slowly.
- **Flick:** Scroll or move quickly. Touch to stop.

Tip: If your screen goes to sleep, press Menu to wake it up.

Home

The *home screen* gives you all your latest information in one place. It's what you see when you turn on the phone or press Home from a menu.

Use the widgets, shortcuts and panels to see what's important to you—whether it's home, work or play. To make the home screen yours, see "Personalize".

Personalize

Go ahead, add your personal touch. Change your widgets, wallpaper, ringtone, and more—make it yours.

- **Home screen:** To add something or change your wallpaper, touch and hold an empty spot until you see the **Add to Home screen** menu.

  Tip: To move or delete something, touch and hold it, then drag it to another spot, another panel, or the trash can.
- **Ringtones & sounds:** Press Menu > **Settings** > **Sound & ringtones**.

* If you use a wired headset with built-in microphone, you'll need to use an OMTP (*Open Mobile Terminal Platform*) compliant headset, such as the Motorola OH15. Look for the OMTP logo shown here, or go to www.motorola.com/wired for additional information.





Make a note:

Your MOTOBLUR ID: _____

Your MOTOBLUR password: _____



Phone Status & Notifications
Flick down to see details.
Online Status Widget
Tell your friends what you're up to.
Widgets
See your latest updates and more.
Panels
Flick left or right to open more panels of widgets.
Shortcuts
Jump to an app, web page and more.
Open the app tray.

MOTOROLA and the Stylized M Logo are registered in the US Patent & Trademark Office. The MOTOBLUR Logo is a trademark of Motorola. The Bluetooth trademarks are owned by their proprietor and used by Motorola, Inc. under license. Facebook is a trademark of Facebook, Inc. Google, YouTube, Picasa, Gmail, and the Google logo are trademarks of Google, Inc. Wi-Fi is a Certification Mark of the Wireless Fidelity Alliance, Inc. All other product or service names are the property of their respective owners.
© 2010 Motorola, Inc. All rights reserved.
Caution: Changes or modifications made in the radio phone, not expressly approved by Motorola, will void the user's authority to operate the equipment.

Bluetooth ID: B016118

MOTOROLA QUENCH with MOTOBLUR (MB501)
Manual Number: 68000202946-A

Apps

You can find all of your apps in one place. From the home screen, just touch [ ] or press Home [ ] to open and close the app menu.

Tip: To find an app in the menu, press and hold Menu [ ] to open a keypad, then type the app name.

Want more? No problem: To download more apps, touch [ ] > **Market**.

Note: You might not have some features. For details, ask your service provider.

Calls

Your dial pad and call lists are just a touch or two away—no menus needed. Just touch **Dialer** from the home screen.

Tip: During a call, press Home [ ] or Back [ ] to hide the active call display and use other apps. To reopen it, touch **Dialer**.

Contacts

Now you have contacts like you've never had before, downloaded from your accounts and backed up on MOTOBLUR. View, search, and use them your way. Touch **Contacts** in the home screen.

Tip: When you flick or drag this list, a scroll bar appears on the right. Drag the scroll bar to move the list faster. To search the list, press and hold Menu [ ] to open a keypad, then type a name.

Updates

Find out what everyone is doing. Touch your **Messages** or **Happenings** widgets to see the newest update, then:

- **See more:** Flick left to see more updates or messages.
- **See details:** Touch [ ]. Then, in **Happenings**, you can touch the social network's icon for more access.

Tip: To add social network or email accounts, press Menu [ ] > **Settings** > **Accounts** > **Add account** and sign in with that account's user name or email.

Messages

All of your messages stay in one place—text, IM, email, Facebook, and more. Touch **Messaging** > **Universal Inbox**.

Tip: To type in a message, touch a text field to open the touchscreen keypad.

Media

See it, capture it, share it! You'll even have time to relax to some music.

- **Photos:** press Camera [ ] and press again to take your photo.
- **Videos:** press Camera [ ] > Menu [ ] > **Camcorder**, then press Camera [ ] to record your video.

  To see what you've taken, touch [ ] > **Picture Gallery** or **Video Gallery**.
- **Music:** touch [ ] > **Music**

Web & maps

Browse, download, and search (of course). And if you need to know where you are or where you're going, we've got that covered too.

- **Browser:** Touch [ ] > **Browser** and surf to your heart's content using the super fast 3G and Wi-Fi connections.
- **Maps:** Touch [ ] > **Google Maps** to use the Google Maps™ you know and love. With built-in GPS, you'll have pinpoint navigation all the way.

Wireless

Lose the wires—press Menu [ ] > **Settings** > **Wireless controls**.

- **Bluetooth™:** For handsfree calls and wireless music, touch **Bluetooth settings** and connect to your accessory.
- **Wi-Fi™:** For fast internet access, touch **Wi-Fi settings** and connect to a home, office or hotspot network. For connection details, press Menu [ ] > **Advanced**.

Tip: To quickly turn wireless features on or off, press and hold Power [ ] until the power menu appears.

Tips

Here are some good things to know:

- **Save Battery:** Press and hold Power [ ], then touch GPS, Wi-Fi™, or Bluetooth™ power to turn them off when not in use.
- **Notification LED:** To turn off the LED, press Menu [ ] > **Settings** > **Display & security** > **Notification LED**.
- **See Recent Apps:** Press and hold Home [ ].
- **Search:** Press Search [ ].

More

There's more help, more accessories, more free stuff. We're here to help.

- **Help:** Check out the help center on your phone—touch [ ] > **Help Center**. Get more help online at **www.motorola.com/myquench** or call 1-800-461-4575.
- **Accessories:** Find more for your phone at **www.motorola.com/products**.
- **Load your files:** Download Media Link at **www.motorola.com/mymedialink**.
- **MOTOBLUR:** Go see your MOTOBLUR account at **www.motorola.com/mymotoblur**.






Universal Inbox (6)
Alex Pico
Some guys have all the luck—the... 8:34 PM
Right now, you're busy flexing...
Seth Rementer
The cinnamon bun place is right next to the store. It's like 6 ... Sep 25
Keith Zang
Job
It's only a freelance gig, but ... pays... Sep 25
Kate Shunney
I have so much energy today, I have no IDEA why. Sep 25
Marianna Bukvic
Running Sep 25
Yi Liu
Re: Weekend Plans Sep 25
Check for Messages Now
Create Messages
Any type, just touch here.
Message List
Touch to open a message. Touch & hold to move, delete, and more.
Message Type
Message Status
unread
urgent
has attachments






Type, then touch the icon to search.
In the browser:
www.google.com/ Google
Zoom In/Out
Pinch your fingers together to zoom out. Drag your fingers apart to zoom in.
Magnify
Touch to open a magnifying window that you can drag.